HOW MUCH AIR SHOULD BE PUMPED INTO THE BOARD





The recommended pressure is marked on the valve rubber patch of each chamber of the board.



Any higher you risk over-inflating and damage.

