
HOW TO USE HIGH PRESSURE VALVE








Open the valve cap by twisting counter-clockwise.



Push valve button in and turn 90 degrees.





Valve button popping up to the "UP position" for inflation. Valve button locked in "DOWN position" for deflation.